

Packing List

FX-600	Unit, Lock key, Instruction manual
FX-601	Unit, Lock key, Instruction manual



FX-600 with 605M

Option

Part No.	Name	Specifications
633-01	Iron holder	With 599B
633-02	Iron holder	With cleaning sponge
605M	Iron cover	-
B3720	Tip enclosure	With nut, required when converting from the FX-600 to the FX-601
B3730	Nut and tip enclosure	Required when converting from the FX-601 to the FX-600

* For information on the iron holders, see P.47.

Replacement Tips for the FX-600

Unit: mm

T18-B Shape-B 	T18-BL Shape-BL 	T18-C05 Shape-0.5C 	T18-C08 Shape-0.8C 	T18-C1 Shape-1C
T18-C2 Shape-2C 	T18-C3 Shape-3C 	T18-C4 Shape-4C 	T18-C5 Shape-5C 	T18-CF1* Shape-1C
T18-CF15* Shape-1.5C 	T18-CF2* Shape-2C 	T18-CF3* Shape-3C 	T18-CF4* Shape-4C 	T18-CSF25* Shape-2.5CS
T18-D08 Shape-0.8D 	T18-D12 Shape-1.2D 	T18-D16 Shape-1.6D 	T18-D24 Shape-2.4D 	T18-D32 Shape-3.2D
T18-DL12 Shape-1.2DL 	T18-DL2 Shape-2DL 	T18-DL32 Shape-3.2DL 	T18-I Shape-I 	T18-BR02 Shape-0.2BR
T18-K Shape-K 	T18-S3 Shape-S3 	T18-S4 Shape-S4 	T18-S6 Shape-S6 	T18-S9 Shape-S9
T18-SB Shape-SB 	* These tips are tinned on the soldering surface only.			

Replacement Tips for the FX-601

Unit: mm

T19-B Shape-B 	T19-B2 Shape-2B 	T19-C3 Shape-3C 	T19-C4 Shape-4C 	T19-C65 Shape-6.5C
T19-D24 Shape-2.4D 	T19-D32 Shape-3.2D 	T19-D5 Shape-5D 	T19-D65 Shape-6.5D 	T19-I Shape-I