




MAGNIFIER WORKBENCH LAMPS



Pro'sKit®
寶工實業股份有限公司
PROKIT'S INDUSTRIES CO., LTD.
<http://www.prokits.com.tw>
E-mail: pk@mail.prokits.com.tw



Pro'sKit®



MAGNIFIER WORKBENCH LAMPS

MAGNIFIER WORKBENCH LAMPS



Thank you for purchasing the Magnifier Workbench Lamps series

REPLACEMENT OF LAMP:

1. Switch off the magnifier lamp and take out the plug.
2. Take off transparent lamp protection cover.
3. Replace the broken lamp with a new one.
4. Put on the lamp protection cover.

HOW TO REPLACE STARTER:

1. Caution: Switch off the lamp, unplug it from power supply and allow the tube cool down before continuing.
2. Remove the lamp from the clamp and lay it on flat surface with the diffuser uppermost.
3. Remove the diffuser gently.
4. Using a suitable screwdriver remove the 3 screws metal clips which carefully the tube and lens into the head.
5. Remove the tube from the head and gently unplug the 4-pin connector.

Data and specification:

Lens: 2.25X(50)
Lamp Type: 22W circular fluorescent lamp
Ballast: 22W

Operation Steps

Clamp the bracket to the edge of any horizontal surface which you have chosen. Insert the bottom stem of the arm into the hole in the bracket. Plug in the magnifier lamp.

Pro'sKit®

4

1

Pro'sKit®



MAGNIFIER WORKBENCH LAMPS

MAGNIFIER WORKBENCH LAMPS



6. Remove the tube and reflection board.

7. Remove the bad starter by twisting it anti-clockwise. Replace the new starter is securely locked into place by twisting it clockwise.
8. Install the reflection board and tube once again. Using the same screwdriver hand-tie the 3 screws metal clips with tube and lens.
9. Install the diffuser once again.
10. Make sure the tube and lens is securely locked on metal clips.

Important for safe use:

1. Indoor use only.
2. Never disassemble the magnifier lamp unless you are qualified electrician.
3. Plug must be taken out while repairing the magnifier lamp.
4. The magnifier lamp can only be mounted on horizontal surface with thickness from 0.5"~2.5".
5. If the external flexible cable or cord of the magnifier lamp is damaged, it should be replaced by a special cable or cord exclusively available from the manufacture or its agent.

TROUBLESHOOTING

Tube not working:

1. Make sure A/C power cord is securely connected to a power outlet.
2. Turn on power switch.
3. Check starter or tube is OK.

Pro'sKit®

2

3

Pro'sKit®